



The Kitch – Grill Operating Instructions

The grills are not supplied with propane tanks; instead they are on a direct line to natural gas. With that, 60 minute timers have been installed to ensure the gas doesn't stay on for more than 60 minutes. Please do not try to turn past 60 minutes as it may break the timer and then the grill is no longer operational. The grills are infrared, which means you will cook your food quicker than you would at home.

- Step 1:** Below grill is the door for the gas timer. Open the door and turn the timer **CLOCKWISE** to desired amount of time. **(See Figure 1)**
- Step 2:** Push and turn the far right pilot valve knob to “pilot” position. Make sure lid is open. **(See Figure 2)**
- Step 3:** Rotate ignitor knob Clockwise several times (small black knob on far left). You will hear a snapping sound, indicating that a spark is being delivered to the pilot. You may need to rotate the knob several times before the pilot is lit. **(See Figure 2)**
- Step 4:** Once lit, rotate burner knobs to the “High” position and burners will ignite. Leave burners at high position to pre-heat grill to desired searing temperature. **(See Figure 2)**
- Step 5:** Adjust burner control knobs to desired cooking levels. **(See Figure 2)**
- Step 6:** To turn off grill, push in and turn burner control knobs and pilot valve knob to the “Off” position. **(See Figure 2)**

(Figure 1)



(Figure 2)

